



# BEN'S TECH TIPS

*Hello it's Ben speaking!*

We receive the question a lot at Tech Support "I made a remote on the KD system for the [Insert part number here], but now the LED on the remote flashes continuously". Certain remotes do require specific remote controls to work with them. RCN02 and DPHY06 for example, require a special crystal inside the remotes. The two types of remotes that contain the special crystal are the B02 and all the coloured 'Luxury' remotes. Other remotes that require specific remote controls are the PCF remote controls.

### Some examples:



B02



B01-3-LB



B01-3-LP



NB1

**NB remotes contain transponder chips.**

## How do I know when to use a specific remote?

There are 2 ways to tell. In the KD software when you have selected a remote profile, there is a box labelled 'Remote Type'. In the Remote King Automotive Identifier, there is a similar section labelled 'KD Remote'. In either of these two sections, B series means you can use any standard KD remote the begins with 'B'. If it has anything else, you must follow specifically what it lists. If it says you must use an NB1, but you use an NB2 - it will not work.

### KD Software

RemoteVer **Cer Ver**

KD code

Part No

FCCID

Freq(MHZ)

Tokens

RemoteType



**Remote Type: KD-B01 LUXURY or B02**

### Automotive Identifier

**KD200:** Asia > Nissan > 28268-3S800

**KD900:** Nissan > 28268-3S800

**Token Charge:** 0

**KD Blade:** DT15KD

**KD Remote:** KD-B01 Luxury or KD-B02

**Third Party:** No